

ARCH & FLAT TOP ARBOR ASSEMBLY INSTRUCTIONS

1. LAY TOP UPSIDE DOWN. PLACE SIDE PANEL BETWEEN SPACER BLOCKS.
2. REMOVE ONE SPACER BLOCK AND ATTACH CORNER BLOCK WITH 2-1 ½" SCREWS IN PREDRILLED HOLES. REPEAT UNTIL ALL CORNERS ARE ATTACHED FOR BOTH SIDES.
3. STAND AT 45 DEGREE ANGLE AND ATTACH SUPPORT BLOCK MOUNTED INSIDE TOP TO SUPPORT BLOCK ON TOP OF SIDE PANEL USING 3- 3" SCREWS IN PREDRILLED HOLES.
4. WHEN ARBOR IS IN PLACE, DRIVE IN GROUND STAKES TO DESIRED DEPTH AND ATTACH WITH 2- 2 ½" SCREWS IN PREDRILLED HOLES.

PARTS LIST:

- 6 - 3" SCREWS - SUPPORT BLOCK
- 16 - 2 ½" SCREWS - CORNER BLOCKS
- 8 - 2 ½" SCREWS - GROUND STAKES
- 1 TOP
- 2 SIDE PANELS
- 8 CORNER BLOCKS
- 4 GROUND STAKES

ARCH & FLAT TOP ARBOR COMPONENTS

